



Admiral

by designer Troels Bøgely

Model: GH-10
Material: glass fibre reinforced plastic (GFP)
Installation: horizontal

Installation of the uridan water free urinals is very simple.

If you retrofitting existing flushing urinals with uridan waterless urinals, please ensure that the sewer line is jetted and clean of uric scale before installation.

The uridan urinals work without water, and therefore should only be connected with \varnothing 50 mm drainpipes. Installation should be carried out by authorized plumbers.

1. Mark holes for fitting No. (1) and install it.
2. Insert extension pipe Pos. (D) on the 87° bend Pos. (C). Keep the distance of 100 mm from the wall to the middle of the pipe.
If necessary shorten the extension pipe. Place the 87° bend with the extension pipe on the outlet pipe.
3. Adjust fitting No. (15), mark holes, drill holes and mount fitting No. (15).
4. Remove the 87° bend with the extension tube and put it on the waste trap.
5. Put the urinal with the pipe on the outlet pipe. Lift the urinal and put it on the fitting.
6. Fill the waste trap Pos. (B) full with water.
7. Insert the stainless steel cover Pos. (A).
9. Pour 1 bottle uriLOCK (0,3 liter) over the cover.
8. Seal the gap between the wall and the urinal with silicone. **Please note:** Do not put any silicone on the lower tip of the urinal!

Please leave customer care booklet, cleaning and maintenance instructions and suction device with customer.

