

Installation Instructions

uridan[®] GRP urinals – for concealed waste - Type GH-6.

Installation of the uridan water free urinals is very simple. If replacing water flushed urinals, the waste pipes **should** be descaled before the installation of Uridan urinals.

Uridan[®] urinals work without water, and therefore only need connecting to a standard 50mm waste pipe. Installation should be carried out by those with appropriate plumbing expertise.

1. Take drill template from packing box.
2. Mount bracket no. (1). The urinal hangs on this bracket.
3. Mount bracket no. (14). This bracket supports the elbow.
4. Ensure the correct distance of 107 mm from the wall to the centre of the pipe.
5. Hold the urinal against the wall and slide the urinal down over the bracket no. (1), ensuring the bottom of the waste trap is secured into the waste pipe.
6. Insert the small PVC pipe (B) into the trap and then fill the trap with water.
7. Insert the stainless steel cover (A).
8. Then pour 0.3 litres, (1 bottle) of urilock fluid over the cover.
9. Apply silicon sealant around the edge of the urinal between the urinal and the wall.

The urinal is ready for use now!

Important: Never pour the urilock[®] fluid before the stainless steel cover is inserted.

Please give the cleaning instructions, Uriclean supply and the cover extraction hook to the appropriate person.

