

Installation Instructions

uridan[®] ceramic urinals – for concealed waste - Type KH-6.

Installation of the uridan water free urinals is very simple. If replacing water flushed urinals, the waste pipes **should** be descaled before the installation of Uridan urinals.

Uridan[®] urinals work without water, and therefore only need connecting to a standard 50mm waste pipe. Installation should be carried out by those with appropriate plumbing expertise.

1. Install bracket no. (19). The urinal hangs on this bracket.
2. Install bracket no. (14). The bracket supports the 90° elbow to the drainpipe.
3. Ensure the correct distance of 110 mm from the wall to the centre of the pipe.
4. Hold uridan[®] urinal against the wall and slide the urinal down over the bracket no. 19, ensuring the bottom of the waste trap is secured into the waste outlet.
6. Insert the small PVC pipe (B) into the trap and then fill the trap with water.
7. Insert the stainless steel cover (A).
8. Then pour 0.3 litres, (1 bottle) of urilock fluid over the cover.
9. Apply silicon sealant around the edge of the urinal between the urinal and the wall.

The urinal is ready for use now!

Important: Never pour urilock[®] fluid before the stainless steel cover is inserted.

Please give the attached cleaning instructions, uriclean and hook to the customer.

