

Aquafree Cleaning and Maintenance



The Aquafree cartridge is used in many thousands of standard urinals to enable them to operate effectively without regular flushing. The bio-block in the stem gives a high initial dose after fitting while the bio-block inside the dome lasts for 3 months or more.

The Aquafree cartridge combats odours and blockages by dispensing bacterial spores into the urinal trap, which then become non-pathogenic **live bacteria** that break down urine as their food source. The bacteria multiply to populate the waste pipes.

WARNING: Use of incompatible cleaning chemicals or urinal blocks may disable the active bacteria and therefore cause odours and blockages!

Gentworks Bactericidal Cleaner is recommended.



CLEANING

- Remove debris from bowl
- Spray over all surfaces with Bactericidal Cleaner, mixed 9 parts water to 1 part chemical
- Wipe surfaces



WEEKLY SLUICING/DOSING

To flush away hair and debris that cannot be broken down by the ingredients of the cartridge, mix 900ml of warm water from the washroom hot tap with 100ml of Bactericidal Cleaner, and pour 1 litre of solution rapidly into the urinal. The cartridge does not need to be removed.



CHANGING THE CARTRIDGE (usually every 3 months)

- Pull the cartridge vertically from the waste outlet, then dispose of safely
- Follow the sluicing/dosing procedure described above
- Insert new cartridge and twist slowly until it slots into place



For more info...

Call: 0345 202 4535

Email: support@gentworks.co.uk

Web: www.waterlessurinals.co.uk/product-support